



## 14. Adjustment



#### Maintenance

Check that the bracket is secure and safe to use at regular intervals(at least every three months).
Please contact your distributor if you have any questions.

# Flat Panel Mobile Cart/Floor Stand and Accessories



**ISSUED: MAR. 2014** 

NOTE: Read the entire instruction manual before you start installation and assembly.

# 🛆 WARNING

- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised ONLY as specified in this manual. Improper installation of this product may cause damage or serious injury.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

**IMPORTANT:** Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.

#### AS0246BTW/BTF middle base (x1) base (x2) left cover (x1) right cover(x1) В С A D O $\bigcirc$ universal plate 1 (x1 universal plate 2 (x1) D8 steel washer (x8) D8 plastic washer (x8) G н q left adapter bracket (x2) right adapter bracket (x2) connecting piece (x1) M8 (x4) **D** column (x1) M8x65 (x8) top cover (x1) cable clamp (x8) Μ $\cap$ P N M8x16 (X4) M8x40(X4) 3mm Allen key (x1) 5mm Allen key (x1) 6mm Allen key (x1) Q R S 11 Component (AS0246BTW only) Component (AS0246BTF only) supporting foot (x4) rubber pad (x4) wrench (x1) caster wheel (x2) caster wheel/brake (x2) W X V (Peel off the backing paper from the rubber pad and stick the rubber pad on to the supporting foot. Package M (x2) M5x14 (x4) M6x14 (x4) M8x20 (x4) M6x30 (x4) M-B M-C M-D M-A 0 00

M8x30 (x4)

M-E

washer(x4)


M-F

small spacer (x8)


M-G

big spacer (x4)

M-H




#### 1. Assembling the Base




Attach the left and right base to the middle base using the appropriate screws. Tighten all screws with an Allen key.

#### 2. For the model AS01K installation (Assembly based on the accessories selected by user.)




Attach the power socket to the back of column using the appropriate screws. Tighten all screws with a phillips screwdriver.

### 3. Attaching the Column to the Base




Attach the column to the assembled base using the connecting piece, secure them with the appropriate screws. **NOTE:** Lock the brakes on the casters to avoid any sudden movements during installation.

### 4. Installing the Covers




5. For the model AS02H installation (Assembly based on the accessories selected by user.)

5-1: Installing the host machine rack on the back of the column




Attach the connecting piece to the host machine rack using the appropriate screws. Tighten all screws with an Allen key.

NOTE: With the arrow pointing upward.




Insert the host machine rack to the desired position along the column rails. Tighten all screws to secure it with an Allen key.


- 5-2: Installing the host machine rack on the side of the column (If the power socket is installed on the back of the column)
- Loosen the screws in order to separate the metal plate from the connecting piece.



Attach the previously removed plates to the host machine rack using the previously removed screws. Tighten all screws with an Allen key.




Insert the host machine rack to the desired position along the column rails. Tighten all screws to secure it with an Allen key.




Loosen the knobs to pull one side of the rack to make it keep the maximum space.
Put the host machine in the rack and push gently on one side of the rack to keep it close to the host machine, then tighten the knobs to secure.


Use the adjustable buckles to hold the machine firmly in place.

#### 6. For the model AS02 installation (Assembly based on the accessories selected by user.)




Insert the iron shelf to the desired position along the column rails. Secure it by tightening screws with an Allen key.






Put the DVD into the box gently , then close the box and lock it.


#### 8. Assembling the Universal Plates



### 9. Installing the Cable Clamps




# 10. Installing the Universal Plate




Insert the universal plate to the desired position along the column rails. Tighten all screws to secure it with an Allen key. NOTE: With the arrow pointing upward.


#### 11. Installing the Top Cover




# 12. For the model AS02R installation (Assembly based on the accessories selected by user.)



#### Remove two plastic caps for the camera shelf installation.




Tighten the support rods to the camera shelf.




Insert the support rods to the desired position (Determine the position for support mount keeping in mind display size.) along the column slots and tighten both screws to secure the support mount.


# 13. Installing the Adapter Brackets




#### 13-1 For Flat Back Screens




#### 13-2 For Recessed Back Screens or to Access A/V Inputs




# 14. Hanging the Displays onto the Universal Plates



Lift the display carefully and pull downward two straps at the same time, then hook the adapter brackets to the universal plate. Fasten the adapter brackets to the universal plate by releasing the straps.
The other display is hung onto the universal plate in the same way.
Use the padlocks to prevent the displays from being stolen (The padlocks are not included).



# 13. Cable Management



Run the cables through the cable clamps and the rubber strip.